

CLEANING / WASHING METHOD FOR GLOVE X6 BL, X6(F) BL & SLEEVE SX6 BL

It is important to properly launder and clean your safety gloves/sleeve to increase its lifespan and keep you hygienically clean.

It also helps to save money in the long run and achieve green initiatives by reducing waste.

We recommend the following steps to wash the knitted cut resistant gloves and sleeve liner safely :

1. Use neutral detergent or eco-friendly detergent (do not use dry cleaning solutions).
2. Wash for 20 minutes in warm water, do not exceed 40°C-60°C
3. Rinse for 20 minutes in warm water, do not exceed 40°C-60°C.
4. Tumble dry for 10 minutes, recommended temperature 60°C.

If the gloves contain of oil or food residue from food/meat processing, you may use the below step for washing in order to kill the germs :

1. Machine wash the gloves with 15% lactic acid or anti-bacterial laundry detergent for 5 minutes at room temperature.
2. Rinse the gloves for 5 minutes at room temperature.
3. Wash the gloves with 2% LBS (Lauryl Benzyl Sulphonate) or mild detergent for 30mins at 90°C.
4. Rinse for 5 minutes at room temperature for 2 times.
5. Spin for 1 minute at 1200rpm.
6. Tumble dry for 20minutes at 80°C.

DISCLAIMER:

1. Do not use water at very high temperatures as extreme heat can change the construction of the gloves.
2. Do not use bleach or fabric softener as it may wear away the fibers in the glove and affect the gloves protection level.
3. Do not dry clean and iron.
4. Laundering a glove may impact its performance overtime especially when coating/dip is removed.
5. Sumirubber do not accept any liability once glove have been washed.



X6 BL



X6(F) BL



SX6 BL